

# **E-Stop FELICE protocol**

## E-Stop FELICE reboot



1. Take the “mysteriously secret” key from the control room.
2. Also take the keys which has the “verdeler” label on it and ofcourse take the masterkey.
3. Go to FX0 and to the mains power room (behind FX00.31), located in the back of the building.
4. Use the “mysteriously secret” key to enter.



5. Use the “verdeler” key to reset the power at the FELICE HALL via the keyswitch S1.
6. When the green light in the panel lights up the power of the USERSTATIONS is recovered.

7. Go into the FELICE HALL push the green buttons “IN” on BGKK-1 and BGKK-2.



8. Next go down to the FTA and reset the RSS by turning the reset key.



9. After this continue the separate machine lists to recover both machine back to it's running state.